

Winters Performance Products, Inc.

1580 Trolley Road York, PA 17408 USA 717-764-9844 www.wintersperformance.com

Short Threaded Ring Gear Bolt Kit KIT P/N 93818


 Make certain ring gear bolts and tapped holes in ring gear are clean and oil free.

Use red Loctite® on threads.
Mount ring gear and align holes.

- Install bolt through washer and thread into ring gear. Make sure that washer is lubricated and installed as shown.
- Torque ring gear bolts in a criss-cross pattern to 35-40 FT-Lbs, then final torque to 60 FT-Lbs.
- Bolts should protrude evenly out the tooth side of the ring gear.

Any perceptible variation - Bolts must be re-torqued.

Note: Use FT-LBS scale only. Not M-KGS or Newtons.



Caution: When using a steel spool, ring gear bolt must be shortened to allow for clearance between bolt end and center housing.